


KONKA

P2972S、P2961S、P2171S、P2977S、T2926、T2526
T2976S、T2975S、T2176S、T2576S、P2572S、P2172S、T2173S

型彩色电视机电原理图 (1/2)

P2972S、P2961S、P2171S、P2977S、T2926、T2526
T2976S、T2975S、T2176S、T2576S、P2572S、P2172S、T2173S



T2976S、T2975S、T2176S、T2576S、P2572S、P2172S、T2173S

REM-REC_BOARD

